

CAR MAGNET

Four easy steps to applying your car door magnet



1

Clean product and surface with mild detergent, wiping dry with soft cloth. Ensure that surface paint and coats have dried (see reverse for drying times).



2

Apply Magnet to a dry metallic surface free of curves, bumps or molding. Sleek and strong, these magnets are designed to stay affixed at high speed.



3

Make sure the Magnet is flush to surface, eliminating bubbles and flattening any bent corners.



4

Clean and dry under the magnet weekly. Remove when not in use, as long-term outdoor exposure can cause fading. Remove magnet before washing your car.

These Terms of Use establish the proper use and maintenance of the Car Door Magnet product (hereafter referred to as the "Magnet").

Application Instructions*

1. Preparation

- Prior to application, clean the metallic surface and the Magnet with a mild detergent. Wipe with a soft cloth and allow to dry. Follow the recommendations on the detergent and those of the car manufacturer.
- The Magnet should be at room temperature when applying.
- Use care in handling the Magnet in extremely cold conditions, as the magnetic material can become brittle.
- Make sure to remove the Magnet from any vehicle before a car wash.

2. Determine the location to place the Magnet

- Ensure surface is metallic, smooth, and flat or only slightly curved.
- Don't apply the Magnet on an area that isn't steel or that has extensive non-metallic fillers. Aluminum, wood or fiberglass will not function as a surface.

3. Affix the Magnet onto the surface

- Make sure the entire Magnet is flat against the metal surface.
- Do not place over protrusions (molding, decals, pin stripping, etc.) or concave areas.
- Ensure that there are no air pockets or moisture between the Magnet and the vehicle surface and that corners and edges are smooth and flush with the surface.
- Curvature on the edges of the Magnet may result in it falling off.
- To adjust the location of the Magnet after placement, remove completely and reposition by lifting at the sides to remove; do not remove from the corners. Please note that sliding the Magnet into position may cause stretching and/or scratching.

4. Maintenance and storage

- Remove the Magnet carefully for cleaning at least weekly, though some climates or conditions may require daily cleaning.
- Lift the Magnet carefully on the sides, do not pull the Magnet off by the corners first.
- Do not remove the Magnet with any sharp objects or fingernails.
- Make sure the Magnet and the corners or edges do not get buckled or folded when removing.
- Clean both the Magnet and the metal surface with a mild detergent and wipe with a soft cloth or allow to air dry.
- Store the Magnet flat in a clean, dry place when not in use.
- Don't place other objects on top of a stored Magnet.
- Don't store with magnetic surfaces facing each other when multiple Magnets are stored together.

WARNING

Failure to review and abide by these warnings could result in damage to the Magnet or your vehicle and could increase the likelihood that the Magnet will not adhere properly and may fall off during use.

- Magnets are recommended for city driving only.
- Please take off Magnet and clean vehicle surface at least once a week before re-installing
- Never use a Magnet if it contains any bubbles, wrinkles, bent corners or is otherwise damaged.
- Never exceed the speed limit or any recommended maximum speed.
- Don't place the Magnet over protrusions, fixtures or concave areas, such as: molding, lights, reflectors, decals, pin stripes, air intakes, wells and spoilers.
- Never apply the Magnet to horizontal metal surfaces (such as car roofs) and take care not to place it in direct or constant sunlight or extreme heat.
- Don't layer one Magnet on top of another when applied to vehicles.
- Long-term outdoor usage of the Magnet on painted surfaces may result in fading, due to shielding the underlying color from ultraviolet rays.
- The Magnet is not for use under water or on aircraft.
- Make sure to remove the Magnet from any vehicle before a car wash.

* FAILURE TO FOLLOW ANY OF THE FOREGOING INSTRUCTIONS MAY RESULT IN DAMAGE TO THE MAGNET ITSELF AND TO THE SURFACE ON WHICH THE MAGNET IS AFFIXED, AND MAY ALSO INCREASE THE LIKELIHOOD THAT THE MAGNET WILL NOT ADHERE PROPERLY AND MAY FALL OFF DURING USE. ORGANO GOLD WILL NOT BE LIABLE TO YOU OR ANY THIRD PARTY CLAIMS, LOSSES OR OTHER DAMAGES TO THE MAGNET, THE SURFACE TO WHICH IT IS AFFIXED, OR ANY OTHER PROPERTY OR PERSON, INCLUDING WITHOUT LIMITATION DAMAGES FOR PERSONAL INJURY, CAUSED BY ANY ABUSE OR MISUSE OR OTHER FAILURE TO FOLLOW THE INSTRUCTIONS.